



NELSON TURF


Quality. Service. Guaranteed!

EZ PROTM

8701 Moisture Sensor



Continuous 24V
(OUTPUT)



Resistor*
*8600 EZ ProTM
Series only
(Kit included)

IMPORTANT INFO

- Wire connections are the most important part of sensor installation. You must use the wire nuts and DBY grease connectors (included) to ensure an adequate connection and for the unit to function properly.
- Sensor needs to be installed in an area that is the most representative of the entire landscape being irrigated and can be connected to **ANY ZONE**. (Example shows Zone 1)
- Resistor should only be used with the Nelson 8600 Series EZ ProTM controller. Resistor needs to be installed between the common port and the zone that is powering the sensor box (Example shown here: Green Wire is Zone 1).

● Wire Connection Point

Former Black Solenoid Wire
that was hooked to Hot Zone
Wire (Example shows Zone 1).

