



TOP VIEW



SIDE VIEW




1A


GROUND ROD SPHERE OF INFLUENCE
NO SCALE



TOP VIEW



SIDE VIEW




1B

GROUND PLATE SPHERE OF INFLUENCE
NO SCALE




TOP VIEW



DO NOT INSTALL ANY OTHER WIRES OR CABLE
 WITHIN THE SPHERE OF INFLUENCE


SIDE VIEW




* OR BELOW FROSTLINE, WHICHEVER IS DEEPER

FIGURE 2 - UP TO 64 STATIONS, NON-ROCKY SOILS
 NO SCALE

TOP VIEW



SIDE VIEW




* OR BELOW FROSTLINE, WHICHEVER IS DEEPER

FIGURE 3 - UP TO 64 STATIONS, ALL SOILS
NO SCALE




TOP VIEW



**DO NOT INSTALL ANY OTHER WIRES OR CABLE
 WITHIN THE SPHERE OF INFLUENCE**


SIDE VIEW




*** OR BELOW FROSTLINE, WHICHEVER IS DEEPER**

FIGURE 4 - UP TO 96 STATIONS, NON- ROCKY SOILS
NO SCALE

TOP VIEW




SIDE VIEW




* OR BELOW FROSTLINE, WHICHEVER IS DEEPER

TOP VIEW



DO NOT INSTALL ANY OTHER WIRES OR CABLE
 WITHIN THE SPHERE OF INFLUENCE


SIDE VIEW



* OR BELOW FROSTLINE, WHICHEVER IS DEEPER


FIGURE 6 - UP TO 128 STATIONS, NON-ROCKY SOILS
 NO SCALE

TOP VIEW



**DO NOT INSTALL ANY OTHER WIRES OR CABLE
 WITHIN THE SPHERE OF INFLUENCE**


SIDE VIEW



* OR BELOW FROSTLINE, WHICHEVER IS DEEPER

FIGURE 7 - UP TO 128 STATIONS, ALL SOILS
NO SCALE

TOP VIEW



SIDE VIEW




FIGURE 8 - UP TO 256 STATIONS, ALL SOILS
NO SCALE